

Ship 10/19/07

Work Order ID 60668

July 19, 2010 7:04:57 AM



Page 1

Item ID: D206-781-051

Accept



Setup Start



Revision ID:

Stop



Item Name: Floor Protector (Pilot, Co-Pilot and Passenger)

Start Date: 7/19/10 Start Qty: 1.00



Cust Item ID:

Required Date: 7/19/10 Req'd Qty: 1.00



Customer:

Reference:

Approvals: Process Plan: *[Signature]*

Date:

Tooling:

Date:

Run

Start



QC:

Date:

SPC (Y/N):

Date:

Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
Draw Nbr	Revision Nbr								
DSI 9480	A								

100

0.00



DC

Document Control

Memo

0.00

Photocopy bluefile & type labels per PPP D206-781-051/ DSI 9480
CHG001

8/10/07/13

110

Pick Kit

0.00



Packaging

Memo

0.00

Packaging

10-7-1958

120

QC4- 100% Inspect kits for completeness

0.00



QC

Quality Control

Memo

0.00

8/10/07/13

40

Work Order ID 60668

July 19, 2010 7:04:57 AM



Page 2

Item ID: D206-781-051

Accept



Setup Start



Revision ID:

Stop



Item Name: Floor Protector (Pilot, Co-Pilot and Passenger)

Start Date: 7/19/10

Start Qty: 1.00



Cust Item ID:

Required Date: 7/19/10

Req'd Qty: 1.00



Customer:

Reference:

Approvals:

Process Plan:

Date:

Tooling:

Date:

Run

Start



QC:

Date:

SPC (Y/N):

Date:

Stop



Sequence ID/
Work Center ID

Operation
Description

Set Up/
Run Hours

Tool ID

Tool #

Plan
Code

Accept
Qty

Reject
Qty

Reject
Number

Insp.
Stamp

130



Packaging

Packaging

Memo

0.00

Identify and pack for shipping as per PPP D206-781-051/ DSI 9480

Location:

PPP rev: *Draft*

10-7-19

140



QC

Quality Control

QC21- Final Inspection - Work Order Release

0.00

Memo

0.00

10-7-19
MF

Picklist Print

July 19, 2010 7:04:55 AM

Page 1

Work Order ID: 60668



Parent Item: D206-781-051



Parent Item Name: Floor Protector (Pilot, Co-Pilot and Passenger)

Start Date: 7/19/10

Required Date: 7/19/10

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP RevA: New issue DD verified by:EC

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D206-781-011

Manufactured No

110

Each

7.0000

1

1



Floor Protector (Pilot and Co-Pilot)

4167001

Location

Loc Qty

Loc Code

FG010

7

48594

1

50909

2

59785

4



10-7-19

SP

1SP

D206-781-021

Manufactured No

110

Each

3.0000

1

1



Floor Protector (Passenger Cabin)

4167001

Location

Loc Qty

Loc Code

FG040

3

50914

3



10-7-19

SP

1SP

Work Order ID 60668

July 19, 2010 7:04:57 AM

Ship today 19/07



Page 1

Item ID: D206-781-051

Accept



Setup

Start



Revision ID:

Stop



Item Name: Floor Protector (Pilot, Co-Pilot and Passenger)

Start Date: 7/19/10 Start Qty: 1.00



Cust Item ID:

Required Date: 7/19/10 Req'd Qty: 1.00



Customer:

Reference:

Approvals: Process Plan:

Date:

Tooling:

Date:

Run

Start



QC:

Date:

SPC (Y/N):

Date:

Stop



Sequence ID/
Work Center ID

Operation
Description

Set Up/
Run Hours

Tool ID

Tool #

Plan
Code

Accept
Qty

Reject
Qty

Reject
Number

Insp.
Stamp

Draw Nbr

Revision Nbr

DSI 9480

A

100

0.00



DC

Document Control

Memo

0.00

Photocopy bluefile & type labels per PPP D206-781-051/ DSI 9480
CHG001

REFERENCE ONLY

BB 10-7-19

110

Pick Kit

0.00



Packaging

Memo

0.00

Packaging

120

QC4- 100% Inspect kits for completeness

0.00



QC

Memo

0.00

Quality Control